

# opticon

## **BGA Monocular**

User Instructions and  
30 Year Guarantee



**Models**  
**8x42**  
**10x42**

# Main Features

---



- A** 3 stage locking rotating retractable eyecup assembly
- B** Wide band focusing
- C** Objective lens
- D** Lug for connecting monocular strap

Specifications	8x42	10x42
Product Code	30440	30441
Field (m/1000m)	110	89
Close Focus (m)	2	2
Eye Relief (mm)	19	16
HxW (mm)	136x43	136x43
Weight (g)	285	285

## Accessories (included)



Soft Case



Rubber Objective  
Lens Cover



Cleaning Cloth



Nylon Strap

## Accessories (optional)

### **30443 Tripod Mount**

A bespoke sleeve mount providing a secure connection to any photo/video panhead with a 1/4" thread. Mount secures over objective lens housing. Size: 70x70mm  
Weight: 67g



### **40951 UTA 2x with 40947P connection ring**

This optional accessory enables you to convert your BGA Monocular into a high powered long eye relief pocket telescope for improved long range observation.  
Size: 112x46mm Weight: 166g



# User Instructions


---

Monoculars can open up a whole range of new and exciting impressions when travelling on holiday, taken to sporting and leisure events or used as part of a hobby such as birdwatching or astronomy. To help you get the best results from your equipment please read the following instructions carefully.

**Focusing.** To focus at different distances simply rotate the central focusing band until a clear and sharp image is obtained.

**Rubber Eyecups** are designed to position your eyes correctly to get the maximum comfortable field of view with or without glasses and are often unique to each individual monocular.

**Using glasses.** Opticron BGA monoculars provide the full field of view when wearing glasses. To maximise field of view with glasses on, turn the eyecup assembly clockwise into the 'down' position - remembering to return it to the upright position if you or anybody else wants to use the instrument without glasses.



Position 1  
'Down'  
with glasses



Position 2  
With or without  
glasses



Position 3  
'Up'  
without glasses

# User Instructions

---

**Care and cleaning.** Monoculars require little maintenance but occasionally the outside surfaces of the eyepieces and objective lenses will need cleaning. To avoid damaging these surfaces please read the following carefully.

- (i) Gently remove excess dirt and dust using compressed air or blower brush.  
Caution: Hard and persistent rubbing of dirty surfaces can cause abrasive scratches on the surface of the glass which may distort viewing.
- (ii) Breathe on exposed glass surface and then wipe with an optical cleaning cloth in a circular motion until the surface is clean again.

Do not attempt to dismantle the instrument as this will invalidate the guarantee.

**Cold weather.** In cold weather the external lens surfaces may steam up when moving the instrument from cooler air outside to warmer air inside. If this occurs, leave the instrument to stand for a few minutes until any condensation evaporates.

**WARNING** Never under any circumstances use this monocular to view the Sun. Doing so may cause serious damage to your eyes.

We hope you will get a great deal of pleasure from your new Opticron BGA monocular. If you have any problems or damage in any way our Service Department is on hand to help you.

# Guarantee

---

Please keep this Guarantee Card in a safe place

Model:..... Serial No: .....

Purchase Date: ..... Dealer: .....

Opticron BGA monoculars are of a very high quality both in their performance and construction. We guarantee some parts in these instruments for up to 30 years under the following conditions:

- (i) In the case of defects attributable to faulty processing or materials, we will assume responsibility for the labour and material costs during the first 10 years after purchase. We reserve the right to decide whether defective parts should be repaired or replaced.
- (ii) During the next 20 years we will assume responsibility for material costs only, charging corresponding labour costs.
- (iii) We will accept no liability for damage caused by incorrect use, or for any repairs or actions which have been carried out outside our firm.
- (iv) Parts such as carrying straps, rubber eyecups, rubberised coatings etc. are excluded from the guarantee.

This guarantee is in addition and does not affect your statutory rights.

# Registration

---

If you would like to register your purchase with us please visit [www.opticron.co.uk](http://www.opticron.co.uk) and complete the online Product Registration Form.

Alternatively please telephone us during normal working hours on the numbers given. We will need the product name and serial number (if applicable), purchase date and outlet, your name and postcode.

Registration is voluntary and failure to register will not diminish your rights under the guarantee.

## Privacy

Opticron takes your privacy seriously and we do not share personal information with other companies.



**Address:** Opticron, Unit 21, Titan Court, Laporte Way, Luton, Bedfordshire, LU4 8EF, UK

**Phone:** +44 (0)1582 726522 **Fax:** +44 (0)1582 723559 **Email:** [sales@opticron.co.uk](mailto:sales@opticron.co.uk)